

Processing Unit

HIP - 550

User's Manual


- 10th edition -

Suruga Seiki Co., Ltd.

Thank you for choosing Suruga Seiki's product. This manual has been written for the operation of Processing Unit PRO HIP-550. For proper use, please read this user's manual thoroughly prior to using this product and keep it for future reference.

●Cautions for Your Safety

For proper and effective use, please read this manual thoroughly prior to using this product.

Failure to use the product properly as explained in the manual may cause damage or injury. The sign  indicates prohibited actions.



Cautions

• Safety & Proper Operation

- This product is connected to Laser Auto Collimator. Therefore, an operator of this product should have knowledge of handling laser equipment safety.


• Wiring

- When connecting or disconnecting a cable, turn off the power of this product and any instrument connected to the product. Otherwise, it may cause damage to the product.
- Make sure to arrange wiring of I/O connector correctly. Otherwise, it may cause damage to the product.

• Operating Environment

Do not use the product in the following environments:

- Directly under sunlight
- Areas that have much dust or metallic particles
- Near fire
- Much noise, much vibration
- Areas that may have water or oil spill
- Not flat surface
- Corrosive gas and/or flammable gas environment



• Disassembling/Alteration


DO NOT disassemble, alter, or perform any improper repair of this product.
It may cause electric shock. If you have any question trouble, please contact us.



• Repair Request

In case of the following conditions, please unplug a power cable immediately and contact us for repair request. If the product is continuously used, it may cause fire, electric shock or injury.

- Strange sound or smell or smoke coming out of the product
- Power cable is damaged
- Water is spilled over or foreign particle got inside the product
- Product was dropped or cabinet was damaged



I N D E X

1.	INTRODUCTION.....	4
1.1.	PROCESSING FUNCTION	4
1.2.	PRINCIPLE OF MEASUREMENT USING A LASER AUTO COLLIMATOR	8
1.2.1.	Principles of Reflection and External Incidence Measurements	8
1.2.2.	Switching to External Incidence Measurement	9
1.2.3.	Screens in External Incidence Measurement Mode.....	9
2.	PREPARATION.....	10
2.1.	ASSEMBLING	10
2.1.1.	Assembling method.....	11
2.1.2.	Adjusting method	12
2.2.	CONNECTIONS.....	13
3.	MEASUREMENT SCREEN	16
4.	MEASUREMENT CONDITION SETTING.....	18
4.1.	ANGLE MEASUREMENT OPERATION GUIDE.....	18
4.1.1.	New measurement	18
4.1.2.	Measurement Using Saved Setting Data	19
4.1.3.	ZERO SET	20
4.2.	SETTING SCREEN AND SETTING ITEMS.....	21
4.3.	OK/NG	23
4.4.	OFFSET	24
4.5.	MODE.....	25
4.5.1.	BIN(Center of area).....	26
4.5.2.	GRAY (Luminance centroid)	27
4.6.	LEVEL (MAX. LUMINANCE VALUE JUDGMENT)	28
4.7.	CAL(CALIBRATION)	28
4.8.	FILE	29
4.9.	MOVE	30
4.10.	ROTATE (ROTATION)	31
4.11.	MIRROR (MIRRORING)	33
4.12.	ZOOM	36
4.13.	SPOT	37
4.14.	UNIT	38
4.15.	AXIS	38
4.16.	GUIDE.....	39
4.17.	BAUD.....	39
4.18.	AUTO.....	39
5.	OFFSETTILT MEASUREMENT	40
6.	CALIBRATION.....	43
6.1.	CAL MENU	43
6.2.	NOTES ON MODE	43

6.3.	ANGLE CALIBRATION (MODE: MEASURE).....	44
6.3.1.	LAC.....	45
6.3.2.	OPT (Measure).....	45
6.3.3.	CAL (Measure).....	46
6.4.	ANGLE CALIBRATION (MODE: VALUE).....	48
6.4.1.	OPT (Value).....	48
6.4.2.	CAL (Value).....	49
6.5.	SAVE.....	49
7.	COMMUNICATION CONTROL.....	50
7.1.	SERIAL INTERFACE.....	50
7.2.	COMMUNICATION CONTROL.....	51
7.3.	COMMUNICATION COMMANDS.....	53
7.3.1.	Read Calibration Data.....	54
7.3.2.	Read system data.....	54
7.3.3.	Read measure value.....	55
7.3.4.	Reading measurement setting data individually.....	55
7.3.5.	Reading all measurement setting data.....	56
7.3.6.	Zero Reset.....	56
7.3.7.	Zero Set.....	56
7.3.8.	Remote Off.....	56
7.3.9.	Calibration Data Change.....	57
7.3.10.	File Save.....	57
7.3.11.	File Reading.....	57
7.3.12.	System Data Change.....	57
7.3.13.	Changing settings individually.....	58
7.3.14.	Changing all settings.....	59
7.3.15.	OFFSETTILT Switch to the judgment 1.....	59
7.3.16.	OFFSETTILT Switch to the judgment 2.....	59
7.4.	DATA COLLECTION SOFTWARE.....	61
8.	I/O CONTROL.....	62
9.	ERROR MESSAGE.....	63
10.	TROUBLESHOOTING.....	63


1. INTRODUCTION

1.1. Processing Function

The HIP-550 Processing Unit receives and digitally processes the signals from Suruga Seiki's Auto Collimator, and displays the detected angles and the result of acceptance range on an external monitor screen.

This HIP-550 is the succession model to former HIP-500.


Connected Image Chart



*Attached cable can vary from the models.

Feature

- Two kinds of centroid analysis mode. (Center of area · Luminance centroid)
- Image rotation and mirroring
- Offset judgment range
- Luminance judgment function
- ZOOM function
- Offset tilt measurement function (see below)



Old model compatibility

Function		HIP-550	HIP-500(Old model)
Angle Measurement	Single Spot	○	○
Angle Analysis	Center of area	○	○
	Luminance centroid	○	○
User-Friendly Function	Display the luminance value	○	×
	Zoom function(choice of magnification)	○	×
	Image rotation (Switch XY axis)	○	×
	Inverting image (Axis sign inversion)	○	×
	Offset Judgment	○	×
Judgment of Acceptance Range of Acceptance	Circle (d1)	○	○
	Circle2 (d2)	○	×
	Square (XY)	○	○
Parallel I/O	I/O Points	2/1	2/1
	Input Function1 Zero Set	○	○
	Input Function2 Data Output	○	○
	Output Function	Judgment of Acceptance	Judgment of Acceptance
Serial Communication	Interface	RS-232C	RS-232C
	Command Control	○	○
	Data Output	CSV Style	CSV Style

Specification

Item	Specification
Image output signal	NTSC color image signal (BNC)
Operation environment	0~40°C, 20~80%RH (no condensation)
Power consumption	AC adapter (AC100~240V±10% 50/60Hz)/DC12V 1A 以下
Parallel I/O	Insulated type I/O, in:2port, out:1port
Communication port	RS-232C (D-SUB 9-pin)
Size	W160xH50xD105mm(including the rubber legs of 9mm)
Weight	390g

*Appearance and specifications of this product are subject to change for upgrade without advance notice.

·Accessories & Options

This Product comes with the following accessories. Please check if everything is included.

- AC adapter 1
- Laser Auto Collimator - HIP-550 Video Cable 1
- User's Manual 1

Accessory detailed

1)AC adapter

Size : W44xL60xH26

Weight : 120g

Rating : AC100~240V

DC12V 1A or more



2) Video cable for H400/H4500/H600

Model : HBNC-2

Size : 1.5m

Weight : 80g



Unattached with HIP-550/**-P.

Can connected with HBNC-1 or HBNC-3 that is attached to the H350.

3)User's Manual

Size : A4

Weight : 240g

The following option items are available to meet your needs. Please contact us for purchasing option items.


Product		Model	Note
Laser Auto Collimator	Small type with red LD	H350R-C□□□	Measuring Range $\pm 0.5^\circ \sim \pm 1.75^\circ$
	Small type with blue LD	H350B-C□□□	
	With red LD	H400-C□□□	Measuring Range $\pm 0.5^\circ \sim \pm 2.0^\circ$
	With red LD and screen	H400-C□□□S	Measuring Range $\pm 0.16^\circ \sim \pm 0.35^\circ$
	V-type LAC with red LD	H450R-C□□□	Measuring Range $\pm 0.5^\circ \sim \pm 1.5^\circ$
	V-type LAC with blue LD	H450B-C□□□	Measuring Range $\pm 0.5^\circ \sim \pm 1.5^\circ$
	For 2 wavelength (with screen)	H600-C□□□S	Measuring Range $\pm 0.2^\circ, \pm 0.3^\circ$
	For 2 wavelength with red and blue LDs	H600B-C□□□S	Measuring Range $\pm 0.2^\circ, \pm 0.3^\circ$
2-axes Tilt Stage		HB10	For H400-C, H350
		HB11	For H400-CS, H450, H600-CS
Mount		HA10	
		HA11N	High Stiffness Type
Parallel Mirror		HS-0	$\phi 30, t=10$, One side AL coating Parallelism less than 5arcsec.
Wedged Substrate	1° (60 arcmin)	HS-100	$\phi 40, t=10$ Angle accuracy less than ± 10 arcsec.
	0.5° (30 arcmin)	HS-050	
	0.25°(15 arcmin)	HS-025	
	0.2° (12 arcmin)	HS-020	
	0.1° (6 arcmin)	HS-010	
Wedged Mirror	1° (60 arcmin)	HS-100AL	$\phi 40, t=10$ Angle accuracy less than ± 10 arcsec. AL+MgF ₂
	0.5° (30 arcmin)	HS-050AL	
	0.25°(15 arcmin)	HS-025AL	
	0.2° (12 arcmin)	HS-020AL	
	0.1° (6arcmin)	HS-010AL	
Monitor		VCM-562HIP	
DC power source cable		HDC-CABLE1	This cable is supplied power to the LC monitor VCM-562 from the power supply for LC monitor placed on the back of HIP-550. Attached to some set-model or single that included VCM-562HIP.

1.2. Principle of Measurement Using a Laser Auto Collimator

Light emitted from the semiconductor laser is transformed into parallel laser light by the collimating lens.

The laser light that is reflected by the half-mirror back to reflect to object, then collected by collective lens, and focused onto CCD that set on focal length.


Can be measuring object tilt according to get the length of focus point on the CCD.



1.2.1. Principles of Reflection and External Incidence Measurements

In reflection measurement using a common internal laser light source, the optical axis of the reflected light is entered into an autocollimator in double tilt of θ_a

In an autocollimator, θ_a that adjusts tilt of the laser of this $2 \times \theta_a$ a half is displayed as a tilt angle of the measurement object. When measuring the tilt of external laser light source, should be display the angle of incidence of the laser (θ_b) as a measurement angle. Therefore it must be setup refreccion measurement or external incident measurement.



1.2.2. Switching to External Incidence Measurement

Turn power off. Locate the DIP switch in back of the unit and set No.4 pin to ON and all other pins to OFF. The unit will start in external incidence measurement mode when it is turned on.

1)DIP switch




(Note)

- When the calibration is performed, return the DIP switch and checked with internal light source. See “6. Angle Calibration” for detailed information.

1.2.3. Screens in External Incidence Measurement Mode

“EXT” displayed while in external incidence mode

Results are shown in values twice those from internal light source mode




Measurement screen

2. Preparation

This manual assumes the use of Suruga Seiki's Laser Autocollimator (H400 series), 2-axes tilt stage (HB10) and parallel mirror (HS-0). Set those or other units as instructed below.

2.1. Assembling


Attach the Laser Auto Collimator to the 2-axes tilt stage (HB10) and mount the parallel mirror (HS-0). Keep the distance between the laser output of the Laser Auto Collimator and the parallel mirror (HS-0) to the work distance of the Laser Auto Collimator heads (as shown below).




Refer to the following pages about the detailed method of assembling the stand and the tilt stage (if applicable).

2.1.1. Assembling method


Screw on the tilt stage to stand.




The tilt stage may be installed horizontally. In that case, place it in such a way the flat surface of the opposing knob seats is below the tapered surface as shown (along the direction of spring tension).



Screw the autocollimator with attached screws.




Can be controlled θ_X , θ_Y with tilt stage. Also control θ_X with right and left knob, center nob can be controlled θ_Y . Clamp the tilt stage with squeezing the front knob in tapered side.(see next page)




2.1.2. Adjusting method

- 1) Adjust the detected light to the desired position by rotating the right and left knobs (θX) and the middle knob (θY).
- 2) Retighten the right and left knobs as needed for clamping.
- 3) Finally, retighten the middle knob (θY) as needed for pressurizing.



- 3) After clamping, retighten the middle knob (θY) as needed for pressurizing.

2.2. Connections



No.	Name	Function
(a)	LED	Light on when power switch is ON.
(b)	[MENU] Key	Switch the setting screens
(c)	[↑] Key	At Setting screen, press this to select items. Remote Mode should be cancelled when hold down a key for over 3 seconds. The title on upper left of monitor must be changed to [HOST] when remote mode.
(d)	[↓] Key	At Setting screen, press this to select items. Key Lock should be cancelled when hold down a key for over 3 seconds. The title back ground color on upper left of monitor must be changed to blue when key locked.
(e)	[ENT/ZERO] Key	At Setting Screen press this to fix the setting contents. ZERO SET should be operated when hold down a key for over 3 seconds at the Angle Measurement Screen. *2
(f)	LAC Connector (LAC)	Connecting Laser Autocollimator's cable connector (BNC)
(g)	Power supply for LAC (DC-OUT)	Service Power supply for Autocollimator (DC12V) *3
(h)	I/O Connector (I/O)	For wiring input-output signals with external instruments Removable terminal table.
(i)	Communication Connector (D-sub 9-pin, male)	Cross cable for connecting to the RS232 port of the PC
(j)	DC Jack (DC12V/1A-IN)	Connect the dedicated AC Adapter(AC100V~240V required)
(k)	Power Source for LCD Monitor	Power source for LCD monitor (12VDC/0.5A) *1
(l)	Monitor Output Connector	For connecting monitor with BNC cable.
(m)	Power Switch	Switch to turn on or off the power (Work with extra power supply)
(n)	DIP switch (sided)	Optional setting

*1 When connect VCM-562W to the power supply for LCD monitor (k), do not use adaptor provided in LCD monitor. (Need DC power supply cable HDC-CABLE1 when connect to power supply for LC monitor)

*2 ZeroSet

Set the current angle value to zero point. Configuration condition must not memorize.

*3 Power supply for Autocollimator


H400, 450, 600 series and H350R-C175 can get power supply from HIP-550.

Use attachment AC adaptor(HDC6V-850MA) for H350*—C050/C100 cause of DC6V driving.


System Configuration

H350 Series
(HIP Set 550 / Monitor&HIP Set 550 / Full Set 550)


AC100~240V



H400 / H450 / H600 Series
(HIP Set 550 / Monitor&HIP Set 550 / Full Set 550 / High rigidity Set 550)




H350R-C175 Series
(HIP Set 550 / Monitor&HIP Set 550 / Full Set 550)



*1:DC power supply cable (HDC-CABLE1) is attached set model or single piece of kodel that have CM-562HIP.

3. Measurement screen

Display firmware version on upper left of screen for 1 sec. after power on.



***1 Zero point**


Zero point of measurement angle.
Current light spot centroid can be set to zero point with zero set operation of panel key.
(See details 4.1.3.ZERO SET.)

***2 Luminance level**









Display the luminance condition of light spot with level bar. (See next page "Luminance level bar")
The displayed items vary by the measurement function (center of area and luminance centroid)

***3 Measurement value**

Display the measurement value of target spot



Luminance Level Bar

No.	Bar Display	Color	Status	Content
1		Black	Under (Error)	Unmeasurable as the minimum luminance level is not reached. • BIN (Center of area) : Binary level • GRAY (Luminance centroid) : NOIZE level See 4.5.MODE for each levels
2		Yellow	Low	Measurable but unstable due to low luminance value.
3		Green	Good	Three green bars represent the best condition for measurement.
4		Green		
5		Green		
6		Y/G	High	Measurable but luminance is saturating. Luminance centroid:Yellow, Center of area:Green
7		Red	Over (Error)	Unmeasurable due to saturated pixels Pixels over 255 Luminance centroid : 3 pixels or more Center of area : 32768 pixels or more
		赤	Over (Error)	Cannot measure smoothly cause of luminance value is out of range.


4. Measurement condition setting

4.1. Angle measurement operation guide

4.1.1. New measurement

System setting is required before using the HIP-550 for the first time or whenever resetting of measurement conditions is necessary.

Follow setting steps shown below and see the applicable sections(numbers written to the left) for details.




(Note)

- Default settings assuming the use of the Laser Autocollimator are stored in FILE1 before shipment from the factory. Load FILE 1 as needed.
- Do not overwrite FILE1. Otherwise, all default settings will be lost.
- At power on, the system will start with the last saved or loaded file number and mode of operation.

4.1.2. Measurement Using Saved Setting Data

This section applies to the measurement conditions that are set already. See the applicable sections(numbers written to the left) for details. At power on, the system will start with the last saved or loaded file number.



(Note)

- Default settings assuming the use of the Laser Autocollimator are stored in FILE1 before shipment from the factory. Load FILE1 as needed.
- Do not overwrite FILE1. Otherwise, all default settings will be lost.

*1 “Memory Error” will appear when the saved data contain an error at power on. And then, push the [ENT]key and forcibly initialize. After calibration is required after memory initialization. See “6.1.ANGLE CALIBRATION” for details about angle calibration.

4.1.3. ZERO SET

Set the reference (Zero point) at the measurement processing.
Angle is calculated to be reference.

Setting the zero point

The center is to be a zero point.

Zero point can be shifted as needed within the range of measurement.


1) After angle calibration is completed, display a detected light that is to be a zero spot.

Recommend checking reflected value, threshold and focus.

2) Push [ZERO] key over 3 sec.

3) Centroid light spot is to be a zero point.

***Zero point must not save. When the power off, it will be same position as measurement range point.**



• Definition of centers

A. Optical center

The optical center is the unique center of an optical system of the Laser Autocollimator. It is adjusted to the center of the CCD built into the Laser Autocollimator head.

The intersection of the green line is the optical center.

B. Center of measurement range

The center of measurement range is the zero point referenced in angle calibration.

Set with Opt Center of calibration sequence. Prefer to set as same as A, optical center.

C. Zero Point

Should be zero point of measurement value. (Must be same spot zero point and center of acceptance when the single multi mode. Display blue cross-point)

Can be shifted zero point with ZERO SET.


D. Center of tolerance

Display blue cross-point on enlarged display.

Can be offset the center of tolerance (center of pink circle) from zero point at the only offset mode.

4.2. Setting screen and setting items

Various settings can be made with main menu, display setting menu, and communication menu.



Setting items

Main menu

Name	Description	Setting value	Referential page
OK/NG	Sets judgment type (d or XY) and judgment value	d1/d2/XY	4.3
OffSet	Offsets the center of judgment for X and Y input values	On/Off	4.4
Mode	Sets the method for calculating gravity center of light spot and detection threshold value	BIN/GRAY (35 to 254)	4.5
Level	Sets On/Off, upper and lower limits of brightness level judgment	High/Low (35 to 254)	4.6
View	Opens the display setting menu	—	—
COM	Opens the communication setting menu	—	—
CAL	Calibrates the angle	LAC range	4.7
File	Reads out / saves the setting data	1 to 5	4.8

Display setting menu

Name	Description	Setting value	Referential page
Move	Sets the movement mode	Spot/Axis	4.9
Rotate	Sets the rotation display	No rotation /: rotation by 90° in anticlockwise direction / rotation by 90° in clockwise direction	4.10
Mirror	Sets the mirror display	No reverse / only X direction is reversed / only Y direction is reversed / X and Y directions are reversed	4.11
Zoom	Sets the zoom display	Off / 4× / 8× / 16×	4.12
Spot	Sets the method for displaying the light spot	Light spot and cross / light spot or cross mark / light spot or cross / cross mark / cross	4.13
Unit	Selects the display unit of angle	deg/sec/mrad	4.14
Axis	Selects the coordinate display	X, Y (axis is not displayed) / X, Y (axis is displayed) / Rad, Tan (axis is not displayed) / Rad, Tan (axis is displayed)	4.15
Guide	Sets the menu guide display On/Off	Off/On	4.16

Communication setting menu

Name	Description	Setting value	Referential page
Baud	Selects the baud rate	9600bps/ 19200bps/ 38400bps	4.17
Auto	Selects the measurement value automatic output interval	33msec/200msec	4.18


4.3. OK/NG

Set the type and value of acceptance

- 1)d1 : d Setting to measurement value of acceptance value 1
Set the angle from center of tolerance
- 2)d2 : d Setting to measurement value of acceptance value 2
Set the angle from center of tolerance
- 3)X-Y : Setting to X,Y measurement value of acceptance value
Set the X,Y angle from center of tolerance


* See 3. about measurement value X,Y

d1/d2 setting



XY Setting

Set the acceptance angle selecting each acceptance range [XL], [XH],[YH],and [YL]




4.4. Offset

Offset the center of tolerance from center of measurement for X,Y input value.

- 1) Select "Offset" and press [ENT] key
- 2) Select [On]
 - a)X : Setting X is center of tolerance offset angle that is changed to number
 - b)Y : Setting Y is center of tolerance offset angle that is changed to number

Offset processing sample

Offset X,Y center of tolerance from center of measurement(blue cross-point)



Offset [Off]
(center of tolerance=center of measurement)

Offset [On]
 Offset value

4.5. Mode

Set the method of the detection of the point

1)BIN (Center of area)

The angle is determined by calculating the center of area based on the valid pixels having luminance higher than the threshold

2)GRAY (Luminance centroid)

The angle is determined by calculating the weighted luminance centroid based on the valid pixels having luminance higher than the defined noise level.





Recommended mode by the purpose (*Objects characterized by scattering light cannot be measured.)

Center of area (BIN) → Mirror, beam splitters, etc.
(Objects of measurement characterized by direct reflection)

Luminance Centroid(GRAY) → Objective lenses, edge , etc.
(Objects of measurement characterized by strained reflection)

■ Center of area measurement

■ Luminance centroid measurement




4.5.1. BIN(Center of area)

- 1) Select "MODE" on the setting screen and press [ENT] key
- 2) Select "BIN" and press [ENT] key
Detected part is displayed in red.
- 3) Adjust levels of binary threshold with [↑][↓] key. When the adjustment is done, press [ENT] key.
When the cancellation, press [MENU/RUN] key.

• about binarization

Binarization refers to setting the threshold using a gradation level between 30 and 254. Pixels over the threshold are considered valid. An error is returned when the number of valid pixels exceeds 32767.



• Important notes about setting

When more than one detected light is in view for threshold setting the light dots must be adjusted as shown below so that there is only one dot.


- 1) Low-light
 - Higher the LD volume of the Laser Autocollimator.
 - Decrease the shutter speed of the Laser Autocollimator
 - Decrease the binary threshold.
 - 2) High-Light
 - Lower the LD volume of the Laser Autocollimator.
 - Focus the beam diameter of the Laser Autocollimator with the pinhole plate so that light lands on the desired measurement point.
 - Increase the shutter speed of the Laser Autocollimator.
- Increase the binary threshold.

4.5.2. GRAY (Luminance centroid)

- 1) Select "MODE" on the Setting screen, and press [ENT] key.
- 2) Select "GRAY", and press [ENT] key.
 Detection range is displayed in red
- 3) Adjust noise level with [↑][↓] key.
 Press [ENT] when adjustment is done. If cancellation, press [MENU] key.

• About noise level

A noise level refers to the threshold defined with a gradation level between 30 and 254. Pixels under the defined noise level are excluded from measurement or calculation.



• Important notes about setting

Adjust the laser output (volume) and shutter speed of the Laser Autocollimator so that only the measurable detected light is measured.

An error is returned (unmeasurable) when the number of saturated pixels (luminance level 255) is 2 or more but the measured value is displayed. (For best results, work with settings that lead to green bars.)

4.6. Level (Max. luminance value judgment)

- 1) Select "Level" on the setting screen and press [ENT] key.
- 2) Select on or off with Off/On.
- 3) Choose On
 - a) High : Set Max of the detected luminance level.
(Must be NG over this level or under 255)
 - b) Low : Set Min. of the detected luminance level.
(Must be NG less than this level or over threshold)

Describe each setting value in relation to judgment.

*The following relation applies to N,L, and H when luminance level checks performed:


$$\text{Luminance value } 35 \leq N < L < H \leq 254$$

If N is greater than L, N is changed to a value smaller than L.

The following applies to N when luminance level check is not performed:

$$\text{Luminance value } 35 \leq N \leq 254$$

Must be "ER" error if luminance level is smaller than N or over 255.



Threshold : N, Lower limit: L, Upper limit: H

4.7. CAL(Calibration)

Angle calibration operation

A new measurement range must be set when using a new Laser Autocollimator.

See page 6 for more details about angle calibration.

Can not be in external incidence measurement mode.

4.8. File

1) Save

Saving setting data

- 1) 1~5 : Angle measurement conditions and system data are saved under the selected number.

2) Load

Reading out setting data

- 1) 1~5 : Load data from the selected number.

An error is returned when no data have been saved under the selected number.

- Default settings assuming the use of the Laser Autocollimator are stored in FILE1 before shipment from the factory.
- Load FILE1 when you wish to return to default settings.

*Each file contains angle calibration data in addition to the conditions of measurement.

Measurement conditions can be saved for up to five autocollimators having different ranges of measurement.

(Note)


- Default settings assuming the use of the Laser Autocollimator are stored in FILE1 before shipment from the factory.

4.9. Move

Select whether the light spot moves or the axis moves for rotation display and mirror display.


- When Spot is selected

The light spot moves for the setting of rotation and reverse.



- When Axis is selected

The axis moves for the setting of rotation and reverse.



4.10. Rotate (Rotation)

The movement directions are matched if the tilted axis direction of object to be measured does not correspond to the movement direction of light spot on the monitor using the setting screen of autocollimator main unit.


- 1) OFF: no rotation (normal)
- 2) L90: rotated by 90° in anticlockwise direction
- 3) R90: rotated by 90° in clockwise direction

- When Spot is selected for Mode

The light spot (video) is rotated in a pseudo manner.



When the rotation is set, the live video of light spot is not displayed on the measurement screen.

(For the substitute display of light spot, follow the display setting shown in "4.13. Spot".)




- When Axis is selected for Mode

The axis is rotated. The light spot does not move.



2) L90 (rotated by 90° in anticlockwise direction)



2) R90 (rotated by 90° in clockwise direction)

4.11. Mirror (Mirroring)

When an object to be measured is declined, the video is reversed and the movement is matched if the light spot moves to the opposite direction of declined direction.


- 1) OFF : not reversed
- 2) *X : the video is reversed to X direction only
- 3) *Y : the video is reversed to Y direction only
- 4) *X*Y : the video is rotated to both of X and Y directions

- When Sport is selected for Mode

The light spot (video) is reversed in a pseudo manner.


When the mirroring is set, the live video of light spot is not displayed on the measurement screen.

(For the substitute display of light spot, follow the display setting shown in "4.13. Spot".)




- When Axis is selected for Mode


The axis is reversed. The light spot does not move.




1) No reverse



2) *X (only X direction is reversed)



3) *Y (only Y direction is reversed)



4) *X*Y (both of X and Y directions are reversed)

Example of processing

Mirror tilted to the left

Mirror tilted to the foreground

Normal setting

(Monitor) Direction of spot movement

(Monitor) Direction of spot movement

Changing setting

Combination of:
Image rotation(L)
ROTATION L
+
Mirroring(X axis only)
MIRRORING X

Match the direction of operation and the spot movement in the screen.

4.12. Zoom


In usage driving into the center of acceptance, it is hard to recognize around the center of acceptance as display of the acceptance range on the screen may be very small depending on an acceptance value. In this case , light spot is in the enlarged area when turning on the zoom setting and center of acceptance is enlarged automatically as the center and displays it.

- 1)Off : Zoom display is not performed.
- 2)x4 : x4 zoom display.
- 3)x8 : x8 zoom display.
- 4)x16 : x16 zoom display.

*The zoom display is displayed by a yellow rectangle according to the zoom specification,


• When OK/NG setting is “d*”

1) Zoom “OFF”




2) Zoom

Center of acceptance




• When OK/NG setting is “XY”

1) Zoom “OFF”



2) Zoom



- The enlarged area is not displayed on a screen at the measurement screen.
- ”ZOOM” appears in the monitor and the detected light disappears while the enlarged view is displayed(only the crossline is visible)
- An acceptance range falling outside of the enlarged view area will not be displayed.
- Display center of acceptance on light blue during the zoom.
- When “AREA” is set to “XY” the view will be enlarged about the center of the rectangle.


4.13. Spot

Select the display type of light spot.


- 1) Spot+C : Light spot and cross are displayed.
If the light spot cannot be displayed, only cross is displayed.
- 2) Spot-M : Light spot is displayed.
If the light spot cannot be displayed, only cross mark is displayed.
- 3) Spot-C : Light spot is displayed.
If the light spot cannot be displayed, only cross is displayed.
- 4) Mark : Cross mark is always displayed.
- 5) Cross : Cross is always displayed.

* If rotation / mirroring is not set to Off at zooming and when the movement mode is not set to the light spot movement mode, the light spot cannot be displayed.


Types of light spot display




Light spot and cross



Light spot



Cross mark



Cross

4.14. Unit

Set the display unit of measurement angle.


- 1) deg : degree
- 2) sec : second
- 3) mrad : milli radian

* The output unit of measurement data by serial communication is [deg] regardless of setting.


4.15. Axis

Set the display unit of axis.


- 1) X,Y : X,Y (axis is not displayed)
- 2) X,Y(P) : X,Y (axis is displayed)
- 3) Rad,Tan : Rad,Tan (axis is not displayed)
- 4) Rad,Tan(P) : Rad,Tan (axis is displayed)




1) X, Y (axis is not displayed)



2) X, Y (axis is displayed)



3) Rad, Tan (axis is not displayed)



4) Rad, Tan (axis is displayed)

4.16. Guide

Switch display / nondisplay of guide message of menu.

- 1) Off : a message is not displayed at the center of the menu
- 2) On : a message is displayed at the center of the menu

4.17. Baud

Set the baud rate of RS-232C.

- 1) 9600 : 9600bps
- 2) 19200 : 19200bps
- 3) 38400 : 38400bps

4.18. Auto


Set the judgment result in measurement value continuous sending mode and sending cycle of measurement value.

- 1) 33msec : 33msec (vertical synchronization signal of video) cycle
- 2) 200msec : 200msec cycle

5. OFFSETTILT Measurement

This means relative tilt is measured mainly on tilt in the neutrality after measuring neutral tilt.

Case of I/O in_1 input is OFF, measure neutral tilt from center of measurement(No.1 judgment:d1).
Case of I/O in_1 input is ON, measure relative angle be position center of measurement the light spot
(No.2 judgment:d1,d2,XY). Should select d1, d2 from XY in OK/Ng of menu.
(As for the 1st. judgment, d1 is fixed.)




Can be saved results of judgment (NG or ER) at the relative measurement with DIP switch.
(See page 33 for setting)

Change to Tilt measurement

Turn on only the third pin of the DIP switch of the processing side in a state of power supply OFF.

Tilt measurement mode can be work after re-switch.

1) DIP switch




(Note)

- Third pin is OFF at the shipment from the factory.


Tilt measurement motion

[OK/NG] setting is d2 (d1<d2)


Absolute measurement (d1 Judgment & Display)



Relative measurement (d2 Judgment & Display)



Offset setting [ON]




(←→ Offset)

Change to Tilt Measurement, Keeping Judgment

When keeping result (ER, NG) of relative measurement, turn on second and third pin of DIP switch on the side of processing in power supply OFF.

After power on again, should be tilt(judgment keeping) measurement mode .

1) DIP switch



(Note)

- At the time of the shipment, the second and third pin becomes OFF.


Judgment results keeping motion

Judgment results keeping is for only relative measurement that IN_1 input is ON. Relative measurement is cancelled and the result that is kept is cleared.


In case of no performing relative measurement, judge at the real time without judgment results keeping.

Process example (relative measurement)


Example1(OK→NG→NG)



Example2(OK→NG→ER→ER)



Example3(OK→ER→ER)



6. Calibration


The calibration is carried out when the autocollimator is changed or the angle is calibrated again.

The angle displacement per pixel of CCD camera built in the autocollimator is decided by the calibration.

* If the calibration is carried out, the setting data when the product is shipped from factory may be deleted, so pay attention to the procedure and the saving sufficiently.

6.1. CAL menu

If you select "CAL" from main menu, the calibration menu is opened.



"MODE" : select the setting method of "OPT" and "CAL" from "Measure" and "Value"


"LAC" : set the range of autocollimator

"OPT" : set the center of measurement range (refer to 4.1.3)

"CAL" : set the angle calibration value

6.2. Notes on MODE

Select the setting method of "OPT" and "CAL" from Measure (measurement input) and Value (value input).



"Measure" : the calibration is carried out measuring the wedge mirror etc. whose wedge angle is known



"Value" : if there is value information of calibration value etc., input the value directly

The procedure for calibrating the angle for Measure (6.3) and Value (6.4) are separately described as following.

6.3. Angle calibration (MODE: Measure)

- The angle calibration requires the reference mirrors such as parallel mirror (HS-O) that is the parallel standard and wedge board (HS-□□□) that is reference angle.
- Adjust the distance between laser beam window of autocollimator and parallel mirror to within the measurement distance of object to be measured described in the catalogue.
- When a wedge board is used, place a parallel mirror on the wedge board to check the number of light spots is one before making an adjustment. When a wedge mirror is used, use it without any change.

For details on each setting item, refer to the section described on the left of each item name.




- The setting is made according to the autocollimator range you specified in the order type when the product is shipped from factory.
- After the measurement range of autocollimator is selected, carry out the angle calibration continuously.
- If the operation is interrupted during the calibration, restart the operation from the beginning.
- The calibration data is saved at the end of calibration. If it is not saved, the content of calibration is not reflected.
- In the mode of external incidence measurement, the calibration cannot be carried out.

6.3.1. LAC

If "LAC" is selected from CAL menu, the measurement range of autocollimator is set.

e.g.) For H400-C100, select 1.00.



6.3.2. OPT (Measure)

If "OPT" is selected from CAL menu, the center of measurement range is set.

If the product is purchased as a set of autocollimator, the optical center of autocollimator in the set is set as a center of measurement range when the product is shipped from factory. Make this setting when the autocollimator is changed or in other cases.




If ENT is pressed, the center of measurement range is set to the current light spot position. In order to set the optical center of autocollimator to the center of measurement range, use the reflected light of a corner cube, for example. X and Y at the lower left of screen indicate the coordinate of light spot for which the upper left of screen is set to origin by pixel unit.

6.3.3. CAL (Measure)

If "CAL" is selected from CAL menu, the angle is calibrated.

ZERO point setting screen




After the parallel mirror is installed, adjust stage so that the reflected light comes close to the green center line of display (center of measurement range) as much as possible and set the current light spot position to ZERO point by pressing ENT. At that time, dX and dY at lower left of screen indicate the difference between coordinates of light spot and center of measurement range by pixel unit, so adjust the stage so that this value becomes 0.

After ZERO point is set, the screen shifts to the wedge angle input screen.

* ZERO point set here is used for just calculating the angle correction value and it is not saved.

Wedge angle input screen




Install a wedge board and a parallel mirror on wedge board, or install a wedge mirror independently. If the reflected light can be obtained, input the angle of wedge and execute the setting by pressing ENT. The calibration value can be calculated with angle of wedge and its reflected light.

Calculate and set the angle calibration value from angle of wedge, current light spot position, and ZERO point set on the previous screen following the formula shown in the next page.

If the Judge is displayed in red, the calculated calibration value is improper. If the Judge is displayed in green, the angle calibration setting is terminated successfully.


$$\frac{\text{wedge angle (deg)}}{\text{light spot - ZERO point (pixel)}} = \text{angle per pixel (deg/pixel)}$$



6.4. Angle calibration (MODE: Value)



- If there is value information of center of measurement range and calibration value of autocollimator, input the values directly.

For details on each setting item, refer to the page described on the left of item name.




6.4.1. OPT (Value)

Set the center of measurement range by setting a value. In the left figure, the screen shifts to the value input screen shown right if "XO" is selected, for example.




6.4.2. CAL (Value)

Input the angle calibration value directly with a value.



6.5. Save

If the center of "OPT" measurement range and "CAL" angle calibration value are changed, the menu shifts to File save screen if CAL menu is quit.



If the file is saved, the settings are reflected, however, if it is not saved, the changed settings return to the values before they are changed.

(CAUTION)

- The setting that is set adoring to the autocollimator is saved in FILE1 when the product is shipped from factory.
- Take note that If the setting is written over FILE1, the setting cannot be reset to the factory setting.

* The measurement condition setting and the calibration data are saved in each file.

Up to five measurement conditions of autocollimator with different measurement range can be saved in one unit of this machine.

If the range of autocollimator is different from setting data, the measurement cannot be carried out properly.

If you do not have parallel mirror for calibration, wedge board, or wedge mirror, please contact the customer service.

7. Communication Control

7.1. Serial Interface

HIP-550 supports data output by RS-232C and command control.

Communication modes

Set the external input transmitting mode

A. External Input Transmission Mode

The result of judgment is sent with the measured value at a rising edge of the HOLD input signal from the external I/O interface (See "8. I/O").

B. Continuous Transmission Mode

This mode sends the results and measured values about 200ms.

(Method of switching to Continuous Transmission Mode)

On (turn down) the switch [2] of DIP switch on the side of HIP-550.

C. Remote Control Mode

A communication command sent from the host equipment enables reading the results and measured values, writing settings, zero setting, etc.

(Method of switching to Remote Control Mode)

Hold panel key [↑] for 3 seconds or longer, it should be remote mode. For cancellation, hold for 3 seconds or longer again. The title must be changed to [HOST] on upper left of screen case of remote mode.

(*See 7.2 "Communication Command" for more details)

RS-232C Connector (Pin assignment)

The RS232C connector of HIP-550 has the following pin-outs.

The RS232C cable for connecting to external equipment is a D-sub 9-pin cross cable.

Pins 7-8 are jumped internally.

HIP-550 side (DE-9P-N(JAE))

Pin No	Signal	Comment
1		
2	RxD	Receive Data
3	TxD	Send Data
4		
5	GND	
6		
7	RTS	Request To Send
8	CTS	Clear To Send
9		


Communication Requirements

- Baud Rate : 9600, 19200, 38400, bps
- Data Bit : 8bit
- Parity : None
- Stop Bit : 1
- Flow Control : None

7.2. Communication Control


A. External Input Transmission Mode

Ex) External input



B. Continuous Transmission Mode

Ex) Continuous transmission



Measurement data is sent in the communication format shown below.

HIP-550 G , *S , *X , *Y , *D , CR LF

G : Header

*S : Judgment result "O"(OK), "N"(NG), "E"(ERROR)

*X:

±	0	.	0	0	0
---	---	---	---	---	---

*Y:

±	0	.	0	0	0
---	---	---	---	---	---

*D:

SP	0	.	0	0	0
----	---	---	---	---	---

 [SP] Space Character


The angle data *X, *Y, *D of the measurement result become the data in "deg" without being concerned with the setting of the menu [Unit].

(Note)


- When judgment is E, measurements are "999999".
- When a label other than an error exists, the label outputs measured value.

C. Remote Control Mode

Ex) Read measured value



Ex) Zero set



*1 An error command is returned if communication error exists.

7.3. Communication Commands

Communication Commands List

No	ID Code	Function	Post-processing
1	W000	Zero reset	Send ACK after zero reset
2	W001	Zero set	Send ACK after zero set
3	W020	Remote OFF	Send ACK after remote OFF
4	R022	Read calibration value	Send calibration value
5	W022	Change calibration value	Send ACK after changing calibration value
6	W030	Save file	Send ACK is save successful
7	W031	Switch load files	Send ACK after load and functional change is successful
8	R032	Load system data	Send system data
9	W032	Set system data	Send ACK after system data change
10	R100	Read measured values	Send measured values
11	R101	Load a set value	Send specified data
12	R102	Load all set values	Send all settings
13	W101	Change a set value	Send ACK after changing the specified item
14	W102	Change all set values	Send ACK after change
15	W111	Change OFFSETTILT judgment1	Send ACK after change
16	W112	Change OFFSETTILT judgment2	Send ACK after change

*Can be supported HIP-500 command type.


Can be replaced to HIP-550 without a problem if already set up the system with HIP-500.

No	ID Code	Function	Post-processing
1	RA	Read measured values	Send measured values
2	RC	Read current settings	Send current settings
3	WA	Zero set	Send ACK after zero set
4	WB	Set acceptance circle range	Send ACK after setting new acceptance circle range
5	WC	Set acceptance square range	Send ACK after setting new acceptance square range
6	WD	Set binary threshold	Send ACK after setting binary threshold
7	WE	Save file	Send ACK at save successful
8	WF	Zero reset	Send ACK after zero reset
9	WG	Set noise level	Send ACK after setting new noise level

See HIP-500 "Users Manual" about command format.

7.3.1. Read Calibration Data

Calibration data is output.



Value	Content	Set point
*1	Calibration data	0.00000~9.99999

7.3.2. Read system data


System data is output.



Value	Content	Set point
*1	LAC TYPE	01~12(2.0~0.16)
*2	Rotate	1: Off, 2: 90°CCW, 3: 90°CW
*3	Mirror	1: XY Off, 2: X On, 3: Y On, 4: XY On
*4	Unit	1: deg, 2: min+sec, 3: mrad

7.3.3. Read measure value

Out put the current angle measurement value.




Value	Content	Set point
*1	Result	O(OK), N(NG), E(ERROR)
*2	Measurement value X	-9.999~+9.999(deg) The space character enters the head in case of 0.000.
*3	Measurement value Y	-9.999~+9.999(deg) The space character enters the head in case of 0.000.
*4	Measurement value d	0.000~9.999(deg) The space character enters the head.

* The angle data of the all of communication command becomes the data in “deg” unit without being concerned with the setting of the menu [Unit].

7.3.4. Reading measurement setting data individually


Current measurement setting data are outputted on the item by item basis.



Value	Content	Set point
*1	item	01 : Binarization level 02 : Noise level 03 : Criteria 04 : Circle 1(d1) - Radius 05 : Square - XL 06 : Square - XH 07 : Square - YH 08 : Square - YL 09 : Circle 2 (d2)- Radius 0A : Judgment X_Offset 0B : Judgment Y_Offset 0C : With or without of Max. luminance 0D : Higher limit of luminance acceptance 0E : Lower limit of luminance acceptance 0F : With or without of judgment offset 23 : Method of center of gravity calculation 25 : Application of ZOOM
*2	Setting data	It is different according to item. Refer to item of Reading all measurement setting data.

7.3.5. Reading all measurement setting data


Current setting is read out.



Value	Content	Set point
*1	Binarization level	035~254
*2	Noise level	035~254 or 035~Lower limit of luminance acceptance
*3	Lower limit of luminance acceptance	035~Higher limit of luminance acceptance
*4	Higher limit of luminance acceptance	Noise level~254
*5	With or without of Max. luminance	1:Off, 2:On
*6	Criteria	1:Circle 1(d1), 2:Circle 2(d2), 3:Square
*7	Circle 1(d1) – Radius	0.001~LAC angle
*8	Square – XL	-LAC angle~XH
*9	Square – XH	XL~LAC angle
*10	Square – YH	YL~LAC angle
*11	Square – YL	-LAC angle~YH
*12	Circle 2(d2) - Radius	0.001~LAC angle
*13	Judgment X_Offset	-LAC angle~0.000~LAC angle
*14	Judgment Y_Offset	-LAC angle~0.000~LAC angle
*15	With or without of judgment offset	1:Off, 2:On
*16	Method of center of gravity calculation	1: Center of area (B i n), 2: Luminance centroid (G r a y)
*17	Application of ZOOM	1:Off, 2:×4, 3: ×8, 4: ×16


7.3.6. Zero Reset

This sets the zero point to the center of the monitor.




7.3.7. Zero Set

This sets the zero point to the detected light in the monitor.




7.3.8. Remote Off

A remote controlled function is released.




7.3.9. Calibration Data Change

The calibration data is changed.




7.3.10. File Save

This saves the current settings in the specified file.




7.3.11. File Reading

Change to the setting data that designated failing number.




7.3.12. System Data Change

The system data is changed.



7.3.13. Changing settings individually

Current measurement setting data are changed by each items.



Value	Content	Set point
*1	item	01 : Binarization level 02 : Noise level 03 : Criteria 04 : Circle 1(d1) - Radius 05 : Square - XL 06 : Square - XH 07 : Square - YH 08 : Square - YL 09 : Circle 2 (d2)- Radius 0A : Judgment X_Offset 0B : Judgment Y_Offset 0C : With or without of Max. luminance 0D : Higher limit of luminance acceptance 0E : Lower limit of luminance acceptance 0F : With or without of judgment offset 23 : Method of center of gravity calculation 25 : Application of ZOOM
*2	Setting data	It is different according to item. Refer to item of Changing all settings.

7.3.14. Changing all settings

All measurement setting data are changed as a group.

Host	W	1	0	2	,	*1	,	*2	,	*3	,	*4	,	*5	,	*6
					,	*7	,	*8	,	*9	,	*10	,	*11	,	*12
					,	*13	,	*14	,	*15	,	*16	,	*17	CR	LF


Time →

HIP-550	W	1	0	2	CR	LF
---------	---	---	---	---	----	----

Value	Content	Set point
*1	Binarization level	035~254
*2	Noise level	035~254 or 035~Lower limit of luminance acceptance
*3	Lower limit of luminance acceptance	035~Higher limit of luminance acceptance
*4	Higher limit of luminance acceptance	Noise level~254
*5	With or without of Max. luminance	1:Off, 2:On
*6	Criteria	1:Circle 1(d1), 2:Circle 2(d2), 3:Square
*7	Circle 1(d1) – Radius	0.001~LAC angle
*8	Square – XL	-LAC angle~XH
*9	Square – XH	XL~LAC angle
*10	Square – YH	YL~LAC angle
*11	Square – YL	-LAC angle~YH
*12	Circle 2(d2) - Radius	0.001~LAC angle
*13	Judgment X_Offset	-LAC angle~0.000~LAC angle
*14	Judgment Y_Offset	-LAC angle~0.000~LAC angle
*15	With or without of judgment offset	1:Off, 2:On
*16	Method of center of gravity calculation	1: Center of area (B i n), 2: Luminance centroid (G r a y)
*17	Application of ZOOM	1:Off, 2:×4, 3: ×8, 4: ×16


7.3.15. OFFSETTILT Switch to the judgment 1

Switch the tolerance from judgment range 2 (d1,d2,X-Y) to judgment range 1 (d1) at the OFFSETTILT measurement.




7.3.16. OFFSETTILT Switch to the judgment 2

Switch the tolerance from judgment range 1 (d1) to judgment range 2 (d1,d2,X-Y) at the OFFSETTILT measurement.



Communication errors

An error is returned from the unit in the format shown below when the command fails to receive or execute normally.



Value	Content	Set point
*1	Error code	1 : Communication error <ul style="list-style-type: none"> • 60 or more characters received between ID Code character and [CRLF] • No characters received within 1 second after ID Code is received • Overrun error or framing error 2 : Setting data error <ul style="list-style-type: none"> • A set value falls outside of the setting range (When Setting command is used, this error may occur when the relative size is invalid.) 3 : Command format error <ul style="list-style-type: none"> • The number of characters between ID Code character and [CRLF] is invalid • Setting data is missing or characters other than numeric characters are used in Set type command • The character following ID Code is not in the above list 4 : Execution error <ul style="list-style-type: none"> • Zero set failed during "WA" command execution as no light dot was detected. • No data have been saved under the specified file number.

7.4. Data collection software

Data Collection Software is an Excel macro program for receiving results of measurement that are sent by serial output.

The software can be downloaded from Suruga Seiki OST Division's homepage (<http://www.surugaost.jp/>).

• Operating environment and operation

You will need Microsoft(R) Excel 2000 or later versions to run the software. You will also need a D-sub 9-pin cross cable for connection to the PC.

• Start

Start Microsoft(R) Excel file "HIP-550 Communication with macros enabled.

• Setting (See "7.1 Serial Interface" about setting in the image processor side)

	A	B	C	D	E	F	G	H
1	ヘッダー	判定	X軸	Y軸	中心からの重心		COM	
2							3	(a)
3							ボーレート	(b)
4							38400	
5							サンプリングタイム(ms)	(c)
6							500	
7							モード	(d)
8							CONT	
9								
10							通信開始	(e)
11								
12								
13							通信終了	(f)
14								
15								
16								
17								

(a) COM

Set the COM port number of the PC connected to HIP-550.

(b) Baud rate

Set the baud rate of communication set on the HIP-550.

(c) Sampling time (ms)

Set the interval for acquiring results of measurement sent continuously from the HIP-550.

(d) Mode

SINGLE: Receive data for a single result when START button is pressed; end when reception is completed.

* Enabled only when the HIP-550 is in Remote Control mode.

CONT: Receive data from the HIP-550 when START button is pressed; continue receiving data until END button is pressed (up to the end line on Excel; 65535th line on Excel 2000).

* Enabled only when the HIP-550 is in "STREAM" mode and set for continuous transmission.

(e) Start button

Press "Start Communication" button in Microsoft(R) Excel file "HIP-550 Communication to start receiving data.

(f) End button


Press "End Communication" button in Microsoft(R) Excel file "HIP-550 Communication to end receive data.

8. I/O Control

Zero Set is performed by short-circuit 1pin and 4pin of I/O connector. The measurement value is outputted by short-circuit 2pin and 4pin. 3pin must be ON during judgment is NG.

• Operation Timing Chart

*1:Period without




(Note) Input signals must remain ON for at least 100ms.

• Electrical Specification

In case of input ON, should be shorted 1, 2pin and COM(4pin).

Use no-voltage contacts for shorting. No-voltage contacts must accept 5mA or higher current with the leakage current of no higher than 0.1mA.



Connector Model

: XW4A-04B1-H1 (Omron)

Compatible Connector Model

: XW4B-04B1-H1 (Omron)

I/O terminal table

Pin No.	Signal Name
1	ZERO Set Input
2	Hold Input
3	NG Output
4	Common (Internal 0VDC)

9. Error message

The error message is displayed under the left of the screen at the error.

Error Message List

Message	Content
Setting ERROR!!	Angle calibration failed.
Memory Error!!	System data loading failed.
No Data !!	Measurement data loading failed.

10. Troubleshooting

Case	Probable Causes	Countermeasure
No power supply	AC adapter is disconnected.	Securely connect to the wall outlet.
No light spot displayed in the screen	Connector cable is disconnected	Connect the cable correctly.
	Laser ON/OFF switch is set to OFF.	Set laser ON/OFF switch to ON.
	Low receiving sensitivity Low light amount	Down the autocollimator's shutter speed or up the lazer power.
	End of the laser life	Contact Suruga Seiki.
Hard to detect laser light	Reflectance of the object is too low.	Adjust the variable aperture of the auto collimator or change the light intensity using the volume.
	Shutter speed is too slow.	Adjust the shutter speed by turning the shutter switch of the auto collimator.

<Revision History>

Edition	Date	Revised Content
First Edition	07/24/2008	New Document
2 nd Edition	09/02/2008	H350AC adaptor type corrected Internal mirror explanation corrected Offset Tilt measurement result keeping function added
3 rd .Edition	10/09/2008	I/O connector terminal table type corrected.
8 th Edition	05/16/2011	Menu change etc.
10 th Edition	05/10/2019	Clerical corrections

For More Information Call to us:

SURUGA SEIKI CO., LTD.

Overseas Section, OST Division

TEL : +81-3-6711-5014

FAX : +81-3-6711-5021

URL : <http://www.suruga-ost.com/>

E-mail : info@suruga-g.co.jp